

MANUAL SECTION	ISSUE DATE	AUTHORISED	REPLACES	PAGE
<i>Adhesives</i>	<i>Sept 2009</i>	<i>PM</i>	-	<i>1 of 2</i>

## QUICKTACK

### Quick drying adhesive for Synthetic Non-woven carpets

**QUICKTACK** is formulated for installing non-woven carpets, as well as some other flooring systems (see Nuplex) . It is water-resistant and creates a very strong bond.

**FEATURES:**

- Tough, yet resilient bond.
- Solvent based, therefore tacks up more rapidly than waterbased systems.
- Will “pull down” reluctant carpets.
- High solids content, therefore gap filling.
- Will adhere well on concrete and/or timber.
- Also suitable for artificial grass carpet in exterior situations. Check base / drainage / coverage rate and conditions first.

**CAUTION:**

1. QuickTack and its vapours are very flammable. Take great care to avoid ignition.
2. The carpet must be heavily rolled into the adhesive and is the progressively rolled until the bond formation is complete.
3. Always test bond an area to determine the suitability with the material being adhered.
4. QuickTack is solvent based; take care that solvent sensitive backings on materials will not be damaged.

**TYPICAL PROPERTIES:**

**Type:** Solvent based mastic; does not contain Toluene  
**Base:** Synthetic rubber/resin  
**Viscosity:** Mastic  
**Density:** Approximately 1.15kg/L  
**Flashpoint:** <0°C, very flammable  
**Storage:** 24 months in unopened containers  
**Packaging:** 20Lt metal tins

No warranty either expressed or implied or statutory is made by NUPLEX in this document except as expressly stated in any sale and purchase agreement entered into between NUPLEX and the buyer. CERTIFIED ISO 9001 REG. NO. 158  
 This document is a technical data information sheet The description of the product or products and the properties of the product or products contained in this document is for the sole purpose of identifying the product or products and describing their property or properties and does not constitute a warranty that the product or its properties shall conform to that description; nor is the description of the product and/or its properties a warranty by NUPLEX that the goods are suitable for a particular purpose.

**QUICKTACK** (cont'd)**SUBSTRATE  
PREPARATION:**

Ensure the substrate is clean and dry and levelled appropriately.  
Use Superset, NC 182 or NC160 for self levelling installations.  
Seal porous substrates with Neoprime if required or in doubt.

**APPLICATION:**

Notch sizes: Versablade 680 KBC or DGD

**Note:**

These are guides only and the use must determine (via the sample) the correct requirement for the material being adhered.

<u>Coverage rates</u>	2 - 3m <sup>2</sup> /Lt
Exterior	1.5-2.0 m <sup>2</sup> / Lt

Always refer to the floorcovering manufacturers recommendations; these always apply in precedence over this data.

Apply the adhesive and allow to tack up slightly. Apply the material into the wet adhesive, checking regularly that transfer of wet adhesive does occur to the back of the material being installed.

Drying is dependent on the condition (porosity) of the sub floor, air movement and air temperature and the porosity of the floor covering. Once trowelled, the floor covering should be laid into the **wet** adhesive.. Ensure the adhesive is **wet** and does transfer under pressure to the back of the floor covering. Correct installation demands a full adhesive spread, **not** spot application.

**Exterior carpets:**

Ensure the concrete surface is clean and dry. Pre-prime with Nuplex Neoprime at 5m<sup>2</sup>/lt and allow to dry before applying adhesive. Use 680-DGD blade for adhesive.

**Note:**

The coverage rates of the adhesive are crucial to a good final result.

Roll the floor with a carpet roller within 10 minutes of installation and continue to do so until a full bond is achieved.

Always record batch numbers of all materials used.

**CURE TIME:**

Non woven will be well bonded within 4 hours.

**CLEAN UP:**

Solvent LA. Caution flammable.